

Micromachined Tunable Optical Filters for Remote Sensing Applications

M.F. Miller, W.J. Marinelli, and M.G. Allen
Physical Sciences Inc.

R.L. Bayt, K.S. Breuer, and M.A. Schmidt
Massachusetts Institute of Technology

David Glenar, Optics Branch
NASA Goddard Space Flight Center

*Presented at the NGST Annual Technology Challenge Review #1
NASA Goddard Space Flight Center, Greenbelt, MD
July 7-10, 1997*

Micromachined Tunable Filter Development

97-2103

- Feasibility of low-order Fabry-Perot filter technology has been demonstrated and a variety of systems have been developed for both mid- and long-infrared applications


Future development focus → increase compactness
reduce complexity

- Microfabrication techniques can be used to fabricate completely solid-state filter assemblies, combining the mechanical advantages of micromachined structures and optical advantages of low-order Fabry-Perot imaging
- New applications become possible
 - ground-, air-, and spaceborne imaging systems
 - spectrometer on a chip
 - cryogenic cooling simplified

Background: PSI's AIRIS System

97-2104

- PSI has successfully demonstrated MWIR and LWIR Addaptive InfraRed Imaging Spectrometer systems (3 to 5 μm and 8 to 14 μm)
- Fabricated using conventional methods
 - piezoelectric actuators
 - capacitive sensing
- Continuous Spectral Coverage over wide wavelength range (1 to 6 μm)
 - millisecond tuning times
 - common pixel registry
- Full spatial image at spectral resolution 1 to 2% λ
- Adaptively sample wavelengths to enhance scene contrast



MWIR AIRIS with commercial InSb camera



Monochromatic Image at $4.66 \pm 0.008 \mu\text{m}$

- Demonstrated
 - optical quality and field uniformity over 7 x 9 deg FOV
 - spectral resolution and out-of-band rejection
 - high throughput - $A\Omega = 0.2 \text{ cm}^2\text{-sr}$
 - portability, reproducibility, ruggedness
- Applications
 - fenceline and fugitive emissions monitor
 - tactical and strategic discrimination
 - compact intelligent remote sensing
 - transient event spectral imaging

Infrared Multi-Spectral Imaging Applications

97-1448a

Science

- Ground- and space-based astronomical observations
- Advanced laboratory instrumentation for infrared spectroscopy
- Compact spectrometers

Industry

- Hazardous waste site/fence line monitoring
 - site awareness
 - disaster assessment
- Rapid materials characterization
 - manufacturing and sorting (e.g., plastics recycling)
 - chemical and pharmaceutical process control
- Combustion gas sensing
 - emissions monitoring
 - sensor for control system



Etalon Basics

97-2105

- Etalon transmission equation

$$\frac{I_t}{I_0} = \left(\frac{T}{1-R} \right)^2 \left[1 + \left(\frac{2F}{\pi} \right)^2 \sin^2 \left(\frac{\delta}{2} \right) \right]^{-1}$$

$$\delta = \frac{4\pi nL \cos(\theta)}{\lambda}$$



R = surface reflectivity

n = index of material between surfaces

Etalon finesse (F) is a measure of the sharpness of the reflectivity fringes

Several factors determine etalon finesse

- surface reflectivity, roughness, and parallelism


Fringe spacing = free spectral range

$$\Delta\lambda = \frac{\lambda^2}{2nL} \quad \Delta L = \frac{\lambda}{2}$$

Fabry-Perot Filter Configurations


97-2106

Filter-On-Optic



D-5006az

Filter-On-Detector



D-5006az

$$\text{Resolution} = \frac{l\Delta\theta^2}{(m+1)}$$

- Best combined spectral resolution and collection efficiency
- Arrays of micromachined filters can be used to achieve large apertures

$$\text{Collection efficiency} = \left(\frac{\pi a \Delta\phi}{2} \right)^2$$

- Compact, potential for very high level of integration
- $f/\#$ of collection lens limited by constraint on angular acceptance

Tunable Filter Performance Goals

97-2107

Spectral Resolution:

$$R = \lambda/\Delta\lambda = 150 \rightarrow \Delta\lambda_{\text{FWHM}} = 25 \text{ nm at } \lambda = 4 \text{ }\mu\text{m}$$

Collection Efficiency:

$$A\Omega = 0.01 \text{ to } 0.1 \text{ cm}^2 \text{ sr} \rightarrow \Delta\theta = \pm 3 \text{ deg, } A = 1 \text{ to } 4 \text{ cm}^2$$

Tunability:

$$\Delta\lambda_{\text{FSR}} \approx 1 \text{ }\mu\text{m}$$

Out-of-Band Rejection:

$$< 1\% \text{ transmission for } \lambda > 3\Delta\lambda_{\text{FWHM}}$$

Cryogenic Operation:

$$T \sim 77 \text{ K}$$

Fabry-Perot Filter Optical Performance

97-815a

Single Element Filter

Single $m = 3$ filter

w/ area = 1 cm^2 ; $F=40$; $R=95\%$, $A=1\%$

$R = 150$ ($\Delta\lambda_{FWHM} = 25 \text{ nm}$)

$A\Omega = 0.02 \text{ cm}^2\text{-sr}$

$\Delta\lambda_{FSR} = 1.0 \text{ }\mu\text{m}$

Out-of-band rejection = 27%

Dual Element Filter

Stack $m = 3$ and $m = 9$ filters


w/ area = 1 cm^2 ; $F=40$; $R=95\%$, $A=1\%$

$R = 150$ ($\Delta\lambda_{FWHM} = 25 \text{ nm}$)

$A\Omega = 0.01 \text{ cm}^2\text{-sr}$

$\Delta\lambda_{FSR} = 1.0 \text{ }\mu\text{m}$

Out-of-band rejection = $<1\%$





D-50072

- Dual-element Fabry-Perot required to achieve $<1\%$ background transmission
- Single element filters may be suitable for some applications

Micromachined Tunable Optical Filter Concept

97-1446a



- Working with MIT on micro-fabrication process development
- Very compact to allow close coupling with camera array
- Single-crystal silicon construction for stable and predictable performance
- Integrated electrostatic actuation and capacitive sensing for adaptive tuning

Fabrication Process Features

97-819a

Fabrication involves deep reactive ion etching and wafer bonding of single-crystal silicon wafers:

- Single-crystal construction
 - well-defined elastic properties
 - no residual stress
 - good optical properties in infrared
- Silicon-On-Insulator (SOI) wafers
 - upper and lower Si layers separated by SiO_2 layer
 - SiO_2 acts as etch stop, simplifying overall fabrication process
 - very uniform upper Si layer: large apertures, arrays
 - polished surfaces for good optical performance
- Reactive Ion Etching (RIE)
 - masking simplified compared to bulk micromachining
 - high aspect ratio structures: good area use efficiency
- Ge/SiO optical coatings
 - materials compatible with semiconductor fabrication processes
 - stress can be controlled through proper design
 - need to use low-temperature bonding

Simplified Fabrication Process

97-2108


SOI Wafer



Plain Wafer



Etch Optical Cavity & Vent




Etch Beam Deflection Clearance Areas



Deposit Dielectric Mirror



Deposit Dielectric Mirror




Deposit Anti-Reflection Coating




Deposit Anti-Reflection Coating



Bond Assembly



Form Bossed Structure and Etch Through Vent




D-5002z

Prototype Filter Array Fabrication

97-2109


- Micromachined basic filter structure to demonstrate feasibility of fabrication process



- 3 x 2 array of 0.5 cm aperture filter structures
- Deep reactive ion etching ~ 300 μm deep structures
- High-temperature fusion wafer bonding (no optical coatings)

Multi-Spectral Infrared Imaging System

97-2110




- Compact filter assembly integrated with camera
- Computer-based control system for filter tuning and image acquisition
- Board level filter control electronics which insert directly into computer expansion bus

D-5419z

Low-Order Fabry-Perot Imaging Filter Module

97-2111



D-54202

- High- and low-order micromachined filters in series
- Compact assembly to be integrated directly in front of a cooled camera array
- Compatible with cryogenic, vacuum environment of camera dewar

Summary

97-2112

- Basic tunable filter design completed
 - micromachined optical cavity with apertures ~ 1 cm
 - Ge/SiO optical coatings
 - integrated electrostatic actuators and sensors for tuning
- Optical coating performance successfully demonstrated
 - good reflectivity and transmissivity over 3 to 5 μm band
 - adequate stress cancellation achieved through proper coating design
- Fabrication process feasibility demonstrated
 - non-tunable structures without optical coatings completed
 - prototypes including optical coatings currently being tested